



**EZ - Ride Suspension**

**Installation manual  
2" front leveling kit  
2005 — 2008 Toyota Tacoma  
Part # 52910**

sj110607rev.01

**Part # 52910  
2005-2008 Toyota Tacoma  
2" front box kit**

<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
52907-01	Pre-load spacer	2
52910-01	Strut spacer	2
M10NLN	10 mm nylon lock nut	1
52910INST	Instruction sheet (customer copy)	1
52910INST	Instruction sheet (installer copy)	1
MIRRORHANGER	Rear view mirror hanger	1
WARNINGDECAL	Warning decal	1

**Important customer information:**

Tuff Country EZ-Ride Suspension highly recommends that a qualified and/or certified mechanic performs this installation.

If you desire to return your vehicle to stock, it is the customers responsibility to save all stock hardware.

This vehicles reaction and handling characteristics may differ from standard cars and/or trucks. Modifications to improve and/or enhance off road performance may raise the intended center of gravity. Extreme caution must be utilized when encountering driving conditions which may cause vehicle imbalance or loss of control. **DRIVE SAFELY!** Avoid abrupt maneuvers, such as sudden sharp turns which could cause a roll over, resulting in serious injury or death.

It is the customers responsibility to make sure that a re-torque is performed on all hardware associated with this suspension system after the first 100 miles of installation. It is also the customers responsibility to do a complete re-torque after every 3000 miles or after every off road use.

After the original installation, Tuff Country EZ-Ride Suspension also recommends having the alignment checked every 6 months to ensure proper tracking, proper wear on tires and front end components. Tuff Country EZ-Ride Suspension takes no responsibility for abuse, improper installation or improper suspension maintenance.

It is the responsibility of the customer or the mechanic to wear safety glasses at all times when performing this installation.

**Congratulations on your selection to purchase a Tuff Country EZ-Ride Suspension System. We at Tuff Country are proud to offer a high quality product at the industries most competitive pricing. Thank you for your confidence in us, and our product.**

**Before installation begins, it is the customers/installers responsibility to make sure that all parts are on hand. If any parts are missing, please feel free to call one of our customer service representatives @ (801) 280-2777.**

**It is the customers/installers responsibility to read and understand all steps before installation begins. OEM manual should be used as a reference guide.**

**Make sure to use lock tite on all new and stock hardware associated with this installation.**

**The Tuff Country EZ-Ride Suspension product safety label that is included in your kit box must be installed inside the cab in plain view of all occupants.**

### Limited lifetime warranty

Notice to all Tuff Country EZ-Ride Suspension customers: It is your responsibility to keep your original sales receipt! If failure should occur on any Tuff Country EZ-Ride Suspension component, your original sales receipt must accompany the warranted unit to receive warranty. Warranty will be void if the customer can not provide the original sales receipt. Do not install a body lift in conjunction with a suspension system. If a body lift is used in conjunction with any Tuff Country EZ-Ride Suspension product, your Tuff Country EZ-Ride Suspension WARRANTY WILL BE VOID. Tuff Country Inc. ("Tuff Country" ) suspension products are warranted to be free from defects in material and workmanship for life if purchased, installed and maintained on a non-commercial vehicle; otherwise, for a period of twelve (12) months, from the date of purchase and installation on a commercial vehicle, or twelve thousand (12,000) miles (which ever occurs first). Tuff Country does not warrant or make any representations concerning Tuff Country Products when not installed and used strictly in accordance with the manufacturer's instructions for such installation and operation and accordance with good installation and maintenance practices of the automotive industry. This warranty does not apply to the cosmetic finish of Tuff Country products nor to Tuff Country products which have been altered, improperly installed, maintained, used or repaired, or damaged by accident, negligence, misuse or racing. ("Racing is used in its broadest sense, and, for example, without regards to formalities in relation to prizes, competition, etc.) This warranty is void if the product is removed from the original vehicle and re-installed on that or any other vehicle. This warranty is exclusive and is in lieu of any implied warranty of merchantability, fitness for a particular purpose or other warranty of quality, whether express or implied, except the warranty of title. All implied warranties are limited to the duration of this warranty. The remedies set forth in this warranty are exclusive. This warranty excludes all labor charges or other incidental of consequential damages. Any part or product returned for warranty claim must be returned through the dealer of the distributor from whom it was purchased. Tuff Country reserves the right to examine all parts returned to it for warranty claim to determine whether or not any such part has failed because of defect in material or workmanship. The obligation of Tuff Country under this warranty shall be limited to repairing, replacing or crediting, at its option, any part or product found to be so defective. Regardless of whether any part is repaired, replaced or credited under this warranty, shipping and/or transportation charges on the return of such product must be prepaid by the customer under this warranty.

Important information that needs to be read before installation begins:

Due to the different variations of the stock strut spring rate, height after installation of the spacer may vary. Any questions please feel free to contact Tuff Country or your local Tuff Country dealer.

Before installation begins, Tuff Country EZ-Ride Suspension highly recommends that the installer performs a test drive on the vehicle. During the test drive, check to see if there are any uncommon sounds or vibrations. If uncommon sounds or vibrations occur on the test drive, uncommon sounds or vibrations will be enhanced once the suspension system has been installed. Tuff Country EZ-Ride Suspension highly recommends notifying the customer prior to installation to inform the customer of these issues if they exist.

Tuff Country EZ-Ride Suspension packages (2) sets of instruction sheets with this box kit. (1) is for the installer and (1) is for the customer. The (1) for the customer has some post installation procedure literature and it is the installers responsibility to make sure that the customer receives a copy of the installation manual along with the literature.

Tuff Country EZ-Ride Suspension highly recommends using a wall mounted strut compressor when installing the strut spacer into the stock strut. If you do not have access to a wall mounted strut compressor, please take it to your local Toyota dealer to have the strut spacer installed into the stock strut.

#### Torque settings:

5/16"	15—18 ft lbs.
3/8"	28—32 ft lbs.
7/16"	30—35 ft lbs.
1/2"	65—85 ft lbs.
9/16"	85—120 ft lbs.
5/8"	95—130 ft lbs.
3/4"	100—140 ft lbs.

#### Recommended tools selection:

Wall mounted strut compressor  
Torque wrench  
Standard socket set  
Standard wrench set  
Metric socket set  
Metric wrench set  
Tape measure  
Hydraulic floor jacks

**Please follow instructions carefully:**

**Before installation begins, measure from the center of the hub, to the bottom of the fender well, and record measurements below.**

**Pre-installation measurements:**

**Driver side front:** \_\_\_\_\_

**Passenger side front:** \_\_\_\_\_

**At the end of the installation take the same measurements and compare to the pre-installation measurements.**

**Post installation measurements:**

**Driver side front:** \_\_\_\_\_

**Passenger side front:** \_\_\_\_\_

**Front end installation:**

1. To begin installation, block the rear tires of the vehicle so that the vehicle is stable and can't roll backwards. Safely lift the front of the vehicle and support the frame with a pair of jack stands. Place a jack stand on both the driver and passenger side. Next, remove the wheels and tires from both sides.

2. Working on the driver side, remove the stock sway bar end link from the stock knuckle. Save the stock hardware for later re-installation. Repeat procedure on the passenger side.

3. Working on the driver side, remove the stock cotter pin that connects the stock knuckle to the stock upper control arm. Save the cotter pin for later re-installation. Loosen but do not remove the stock castle nut that secures the stock knuckle to the stock upper control arm. Carefully break the stock taper in the stock upper control arm and the stock knuckle. Once the taper has been broke, remove the stock castle nut and set aside for later re-installation. Repeat procedure on the passenger side.

4. Working on the driver side, place a reference mark on the driver side strut. This is done so that the driver side strut will be put back into the driver side of the vehicle. Working on the driver side, remove the (3) upper stock nuts that connect the stock strut into the stock location. The stock nuts may be discarded. Repeat procedure on the passenger side.

5. Working on the driver side, remove the stock lower bolt that connects the stock strut to the stock lower mounting location and save the stock hardware for later re-installation. **Special note: During removal of the stock bolt, take special care not to damage the stock CV boot. Also, make a mental note on which way the bolt is removed, it needs to be re-installed the same way that**

**it was removed.** Remove the stock strut assembly from the stock location and set aside for further instructions. Repeat procedure on the passenger side.

**Special Note: Tuff Country EZ-Ride Suspension highly recommends using a wall mounted strut compressor when installing the strut spacer into the stock strut. If you do not have access to a wall mounted strut compressor, please take it to your local Toyota dealer to have the strut spacer installed into the stock strut.**

6. Locate the driver side stock strut assembly. Working on the driver side strut, scribe a line down the entire strut from the top of the strut to the bottom. **Special note: If this step is not performed properly re-installing the strut back into the vehicle will be difficult.**

7. Using a wall mounted strut compressor, carefully compress the driver side stock strut until the upper stock strut bearing plate can be removed. Remove the stock nut and hardware from the top of the stock strut assembly and save the stock hardware for later re-installation.

8. Working on the driver side stock strut, remove the stock upper strut bearing plate from the stock strut assembly. Remove the stock rubber isolator from the stock upper strut bracket and set the stock upper bearing plate and isolator aside for further instructions.

9. Locate (1) new strut spacer, the driver side stock strut, the stock bearing plate, the stock isolator and the stock hardware. Carefully compress the stock strut enough so that the new strut spacer and the stock isolator can be installed. Install the new strut spacer and stock isolator into the stock strut and secure the stock upper bearing plate to stock strut assembly using the stock upper strut hardware. Make sure to use thread locker or lock tite. Torque to **65 ft lbs.**

10. Locate (1) new upper strut isolator spacer and (3) new 10 mm nylon lock nuts that were packaged with the installer copy of the installation manual. Working on the driver side, install the new upper strut isolator spacer on top of the stock bearing plate and install into the stock strut upper location. Secure the top of the new strut assembly using the new hardware. Torque to the new hardware to **42 ft lbs.**

11. Locate the stock lower strut bolt and hardware. Secure the stock strut assembly into the stock lower location using the stock hardware. Make sure to use thread locker or lock tite. Torque to **75 ft lbs. Special note: When installing the stock lower bolt, make sure that the bolt is installed the way it was removed. Facing towards the front of the vehicle. Also, take special care not to damage the stock CV boot when re-installing the stock hardware.**

12. Repeat steps 7 - 11 on the passenger side strut assembly.

13. Locate the stock castle nut and cotter pin. Working on the driver side, secure the stock knuckle to the stock upper control arm using the stock hardware. Torque and install the stock cotter pin. **Special note: when torquing the stock castle nut, DO NOT loosen the stock castle nut to get the holes lined up to install the stock cotter pin, tighten the stock castle nut until the holes line up and the stock cotter pin can be installed.** Repeat procedure on the passenger side.

14. Locate the stock sway bar hardware. Working on the driver side, secure the stock sway bar to the stock knuckle using the stock hardware to **65 ft lbs.**

15. Re-install the tires and wheels and torque the lug nuts to the proper torque specifications. Carefully lower the vehicle to the ground.

16. Check and double check to make sure that all steps were performed properly. Once installation is complete take vehicle directly to an alignment center for proper front end alignment.

**Congratulations, installation complete!**

**Special note: After the completion of the installation, Tuff Country EZ-Ride Suspension recommends taking the vehicle to an alignment shop and having a proper front end alignment performed.**

**Tuff Country EZ-Ride Suspension recommends that a complete re-torque is done on all bolts associated with this suspension system. It is the customers responsibility to make sure that a re-torque is performed on all hardware associated with this suspension system after the first 100 miles of installation. It is also the customers responsibility to do a complete re-torque after every 3000 miles or after every off road use. Neglect of following these steps could cause brackets to come loose and cause serious damage to the suspension system and to the vehicle.**

**Tuff Country EZ-Ride Suspension packages (2) sets of instruction sheets with this box kit. (1) is for the installer and (1) is for the customer. The (1) for the customer has some post installation procedure literature and it is the installers responsibility to make sure that the customer receives a copy of the installation manual along with the literature.**

**If you have any questions or concerns, please feel free to contact Tuff Country or your local Tuff Country dealer.**